

Addendum: Testing the FW-4 & FW-2

The following modifies the "Testing The FW-4 and the FW-2 Installation" section of the FW-4 and FW-2 Installation Instructions.

Step 1 should read:

1. Hold the magnet just UNDER the word "TEST" as shown on the diagram below.

